



Voyager™ s3

User Manual

Table of Contents

Introduction	3
Package Contents	3
Ports & Interfaces	4
Usage Instructions	5
Attaching to Your Computer	5
Attaching a Drive	5
Using a Hard Drive Docked in Voyager	6
Macintosh.....	6
Windows.....	7
Warranty Registration & Support	7

Introduction

Thank you for purchasing the Newer Technology **Voyager S3 SATA Hard Drive Docking Solution**. This guide will help you familiarize yourself with the basic functions of the Voyager S3.



Package Contents

- Newer Technology Voyager S3 SATA Hard Drive Docking Solution
- Power Adapter
- USB 3.0 Cable
- Instruction Manual (not pictured)

Ports & Interfaces

Familiarize yourself with the connections on your **Voyager S3 SATA Hard Drive Docking Solution**. You will use these when using **Voyager S3** to mount hard drives on your desktop.

Top View

1. 2.5" & 3.5" SATA I/II Drive Connector
2. Hinged Flap for 3.5" Drive Access
3. Hard Drive Eject Button
4. Power LED
5. Activity LED



Rear View

6. On/Off Switch
7. Power Plug
8. USB 3.0 Port



Usage Instructions

Attaching to Your Computer

Connecting **Voyager S3** to a Macintosh or a Windows computer is a very straightforward procedure.

1. Plug the AC power cord into the wall and into the DC transformer.
2. Plug the DC cord into the **Voyager S3** power receptacle.
3. Connect **Voyager S3** to your computer via the USB 3.0 connector.

Attaching a Drive

1. Make sure **Voyager S3** is turned off by pressing the power button until the blue power LED is *not* illuminated.
2. Insert your SATA hard drive into the base, as shown below.
3. Press the Power Button to turn **Voyager S3** on.



3.5" SATA Drive




2.5" SATA Drive

Using a Hard Drive Docked in Voyager S3

Macintosh

If the drive has been previously formatted or has data on it, an icon for the drive will show on the Desktop, and you may use it like you would any other external drive.

If you are using a new drive that has *not* previously been formatted, an alert box should appear, giving you the option to initialize the drive.



Clicking the "Initialize..." button will take you to Disk Utility. If you click one of the other buttons, and later change your mind, you can find Disk Utility in **Applications>Utilities>Disk Utility**.

In Disk Utility, you may erase the drive by selecting it from the list of drives on the left side of the window, then clicking on the "Erase" tab on the right.



You will be given an option for the type of formatting you want. The default "Mac OS Extended (Journaled)" option will work acceptably for most instances. The "Name" field is where you can enter the drive's new name.

Once you have selected a volume format and a name, click the "Erase..." button. You will be asked if you are sure you want to erase all data on the drive. If you are sure, click the "Erase" button on the dialog box. After a moment, your drive's icon will appear on the Desktop, and you will be able to use it like any other external drive.

Windows

Special drivers are not required for use with Windows 98SE & higher. If the drive has been previously formatted, the drive will appear under "My Computer" as an external device, and you may use it like any other external drive.

If the drive is not visible under My Computer, it may not be formatted in a way that Windows can recognize. In order to use this drive with your Windows system, you will need to reformat it, keeping in mind that reformatting a drive will erase any data that currently resides on it.

Each version of Windows has a slightly different way of formatting a drive. Step-by-step instructions for each Windows version are available at the web site for NewerTech's distributor, **Other World Computing**, in their online Tech Center. http://eshop.macsales.com/tech_center/harddrives.cfm

Warranty Registration & Support

You can register your **Voyager SATA Hard Drive Docking Solution** at NewerTech's Web site: http://newertech.com/tech_support/ntwty.php

If you need support, there are three ways to contact Technical Support or Customer Service:

- **email**
 - » You can submit your email support request at: <http://helpcenter.newertech.com/>
- **Phone**
 - » 815-308-7001 - Option 2
 - » 8am–10pm CST Monday–Friday
 - » 9am–4pm CST Saturday
- **LiveChat**
 - » NewerTech's distributor, **OWC**, offers live technical assistance at: <http://eshop.macsales.com/>
 - » 8am-8pm CST Monday–Friday
 - » 9am-4pm CST Saturday
 - » 10am-4pm CST Sunday

NWTVOYS3MAN

VOYAGER trademark used under a license from the owner of U.S. Registration No. 3,089,301. All rights reserved.

©2010 Newer Technology, Inc. All Rights Reserved
Revision 2, 5/10 - JD